


# EE16A Lab

## Friday 11am-2pm

TA: Seiya

LA: Cameron, Ed, Ryan






# Imaging - Part 2



## Today's Lab: Single Pixel Scanning

---

- ✗ Circuit from last week measures **light** intensity
- ✗ Projector illuminates card in a controlled way
- ✗ Python programming to reconstruct image




# Setup:





# Circuit From Last Week




Circuit Diagram



Breadboard Diagram





# Sample Images





# Sample Images

Me:




# Sample Images

Nightmare  
Fuel: Lab  
Assistant  
Nick



# Images, Matrices, Vectors



A =  $\begin{array}{|c|c|c|} \hline A[0,0] & A[0,1] & A[0,2] \\ \hline [0] & [1] & [2] \\ \hline [3] & [4] & [5] \\ \hline \end{array}$


index of pixel

A =



vectorize


a =  $\begin{array}{|c|c|c|c|c|c|} \hline [0] & [1] & [2] & [3] & [4] & [5] \\ \hline \end{array}$





## How Scanning Works?

---


Real World Object



Imaging Mask




# How Scanning Works: iPython





mask0 =

```
np.array([ [ 1, 0, 0, 0, 0 ]  
          [ 0, 0, 0, 0, 0 ]  
          [ 0, 0, 0, 0, 0 ]  
          [ 0, 0, 0, 0, 0 ]  
          [ 0, 0, 0, 0, 0 ] ])
```



# How Scanning Works: iPython


Imaging Mask 1



mask1 =


```
np.array([
```

```
[ 0, 1, 0, 0, 0 ]  
[ 0, 0, 0, 0, 0 ]  
[ 0, 0, 0, 0, 0 ]  
[ 0, 0, 0, 0, 0 ]  
[ 0, 0, 0, 0, 0 ]])
```




# How Scanning Works: iPython



Real World Object



Imaging Mask 1




Measurement




# How Scanning Works: iPython

```
mask0 = [[ [ 1, 0, 0, 0, 0 ],  
           [ 0, 0, 0, 0, 0 ],  
           [ 0, 0, 0, 0, 0 ],  
           [ 0, 0, 0, 0, 0 ],  
           [ 0, 0, 0, 0, 0 ] ]]
```





Row 0	1
Row 1	0
Row 2	0
Row 3	0
Row 4	0
⋮	⋮
Row 24	0




# How Scanning Works: iPython

```
mask1 = [[0, 1, 0, 0, 0],  
         [0, 0, 0, 0, 0],  
         [0, 0, 0, 0, 0],  
         [0, 0, 0, 0, 0],  
         [0, 0, 0, 0, 0]]
```




# How Scanning Works: iPython

```
mask2 = [[0, 0, 1, 0, 0],  
         [0, 0, 0, 0, 0],  
         [0, 0, 0, 0, 0],  
         [0, 0, 0, 0, 0],  
         [0, 0, 0, 0, 0]]
```



Row 0	0
Row 1	0
Row 2	1
Row 3	0
Row 4	0
⋮	⋮
Row 24	0



# How Scanning Works: iPython

```
mask0 = [[ 1, 0, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ]]]
```

```
mask1 = [[ 0, 1, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ]]]
```

```
mask2 = [[ 0, 0, 1, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ],  
         [ 0, 0, 0, 0, 0 ]]]
```

H =


	mask0	mask1	mask2
Row 0	1	0	0
Row 1	0	1	0
Row 2	0	0	1
Row 3	0	0	0
Row 4	0	0	0
...	⋮	⋮	⋮
Row 24	0	0	0

What is the total size of this matrix?


How does H relate to the masks?




# How Scanning Works: iPython



What will the scanning matrix's dimensions be?




# How Scanning Works: iPython




What will the scanning matrix's dimensions be?

How many total pixels are in the picture?



# How Scanning Works: iPython


What will the scanning matrix's dimensions be? How many pixels?



A vertical column of 12 binary digits (0s and 1s) representing the scanned data:


1
0
0
0
0
0
0
0
0
0
0
0

Ellipses (...) indicate that there are more rows below the visible ones.



# How Scanning Works: iPython


What will the scanning matrix's dimensions be? How many pixels?




1
0
0
0
0
0
0
0
0

**9x9**


...



# How Scanning Works: iPython



What will the scanning matrix's dimensions be?




# How Scanning Works: iPython

1	0	0	0	0	0
0	0	0	0	0	0
0	0	0	0	0	0




What will the scanning matrix's dimensions be?

How many pixels?



# How Scanning Works: iPython

What will the scanning matrix's dimensions be? How many pixels?



# How Scanning Works: iPython

What will the scanning matrix's dimensions be? How many pixels?


1	0	0	0	0
0	0	0	0	0
0	0	0	0	0



1
0
0
0
0
0
0
0
0
0
0
0
0
0
0



**15x15**

...




# Using H to scan our image!

Mask Projected onto  
Real World Object



Masking  
Matrix H




# IPython Review:

```
for i in range(0,5):  
    print(i)
```

```
A = np.zeros((5,5))  
counter = 0;  
for i in range(0,5):  
    for j in range(0,5):  
        A[i,j] = counter/24;  
        counter = counter + 1
```

```
A = (np.arange(0,25,1)/24).reshape((5,5))
```




# IPython Review:

---

```
>>> import numpy as np  
>>> A = np.array([ [1, 2, 3], [4, 5, 6] ])  
>>> B = np.matrix('12; 34')  
>>> C = np.matrix( [ [1, 2], [3, 4] ] )
```


Some numpy functions:

- A.shape, A.T, np.dot
- A[i , j], A[i , :], A[:, j], A[:, ::-1]
- And many more... **Google is your friend!**




# Tips for a Good Image

---




- ✖ Adjust contrast and brightness of projector
  - ✖ Projector's Home Screen → "Setting"
  - ✖ Change Picture Mode from "standard" to "User" by first pushing OK then right bottom X2
  - ✖ Select Contrast and increase to 100
  - ✖ Select Brightness and decrease to 0
  - ✖ Return back to main menu
- ✖ Focus projector using dial on the side
- ✖ Close the box firmly & scan under dark conditions

## Important Notes




- ✗ You should have your kit from last week
- ✗ Equipment in cardboard box:
  - ✗ Don't break the plastic stand!
  - ✗ Put everything back before you leave!
    - Including Projector's Power
- ✗ Make sure you are using the right com port at all times
  - ✗ Not COM1, and not the debugger



# Notes

- ✗ No signal when testing the oscilloscope on their previous circuit
    - ✗ Unplug P6.0 from MSP and debug if necessary
  - ✗ UART Application Com Port not showing up as an option when scanning
    - ✗ Close serial monitor!
  - ✗ Do not take sharpies from the desk
  - ✗ Limited number of Light Sensors: Share if necessary
  - ✗ If something isn't working, close everything and turn it back on (works 9/10 times)



# FAQ

---

- ✗ **SHIFT+RIGHT CLICK** on a window to open in **CMD**
  - ✗ ‘**ipython notebook**’ to open ipython notebook
- ✗ Point ALS at the index card [and not top of box]
  - ✗ Make sure it's not in the way of projection
- ✗ If no pictures show up, copy the URL and open it in Chrome
- ✗ **Check off:**[tinyurl.com/lab108-checkoff](http://tinyurl.com/lab108-checkoff)
- ✗ **Ask Questions:** [tinyurl.com/lab108-Q](http://tinyurl.com/lab108-Q)

